



Monitor Elevator Products  
125 Ricefield Lane  
Hauppauge, NY 11788  
631-543-4334  
customerservice@mcontrols.com

July 7, 2020

RE: Disinfection of Monitor Elevator Products Fixtures

Monitor cannot promote the use of any one name brand disinfectant. However, we have tested many of our fixture components using the Centers for Disease Control and Prevention's (CDC's) suggested water and bleach solution. Monitor performed a minimum 2-hour full submersion test. Once retrieved from solution, components were wiped down and did not show any signs of wear or weakening.

Components tested consisted of, but are not limited to:

- Braille Tag
- Plastic Halo with verbiage
- Plastic Button Cap
- Engraved and paint filled metal button head

Please find below the bleach solution ingredients and ratios listed on the CDC's website as of 5/6/20.

To make a bleach solution, mix:

- 5 tablespoons (1/3 rd cup) bleach per gallon of water
- OR-
- 4 teaspoons bleach per quart of water

Please Note:

- Bleach used must be intended for disinfecting.
- Do not spray directly on fixture or components.
- We suggest spraying a clean cloth with bleach solution and wiping down the surface.
- CDC recommendation is to leave solution on the surface for at least 1 minute before wiping off.
- Bleach solutions will be effective for disinfection up to 24 hours. After 24 hours, solution may begin to weaken and compromise the effectiveness of disinfecting.

Customer Service  
Monitor Elevator Products